

## K540S / K500ST Spindle Sleeve Lubrication Instruction

- (A) Remove screws # 64 Lift off Handle # 63
- (B) Remove Ground Screw # 33
- (C) Remove six [6] top Gearcase Screws # 29a and # 29b (lift gearcase cover off and set aside)
- (D) Remove gasket # 26 (optional)
- (E) Remove # 1 thru #12
- (F) Place a small brass rod on the rear edge of barrel #17h and tap brass rod until the spindle / barrel assembly can be pulled from gearcase # 23 as an assembly.
- (G) Place plastic on bag on small scale and measure out 18gr. Grease Type Urethyn GE00, part no. 4931624375 (45gr tube) [Stide2]
- (H) Remove the Ram assembly # 18 from the barrel and remove O-Ring #18b (Stide 3). lubricate the ram reinstall O-ring #18b. [Set assembly to the side]
- (I) Stand the Spindle assembly up as shown on [Stide 5 / 6] place the 18 gr. of type "Q" Into the barrel as shown on [Stide 4] Install Ram Assembly # 18 into Spindle Assembly as shown on (Stide 5 / 6).

## Note: 1

Crank Assembly # 38, Piston Assembly # 37, Locking Plate # 36, Drive Sleeve # 35, Spindle Bevel Gear #34, And Clutch Assembly # 34 can all remain in Gearcase # 23. When reinstalling Spindle Assembly into gearcase just align the external splines on the outside of the barrel with the internal splines inside the Spindle Bevel Gear # 34 and align tabs on bearing shield # 13a.







18 Grams of Type "Urethyn GE00" Grease 4931624375



lubrication for Ram with Grease "Urethyn GE00"







The Spindle Sleeve shown is a K540 S SDS - Max

Lubrication specifications for both K540S & K500ST Rotary / Chisel Hammer Spindle Assemblies