


M18FHIWP12-502X BTY. IMPACT WRENCH IN2

4933459693 - M18FHIWP12-502X IN2 - 4000467129





Position	Quantity	Description	Part number	EAN
0001	4	SCREW	4931465309	4058546234096
0003	1	AXIAL BEAR.WASHER	4931465311	4058546234119
0007	3	BALL	4931436148	4002395880935
0009	28	BALL	4931440453	4002395892020
0010	1	BEARING WASHER	4931465313	4058546234133
0014	3	PIN	671565004	4002395825028
0015	1	BEARING WASHER	4931465317	4058546234171
0016	1	BALL BEARING	681340001	4002395824021
0017	1	GASKET	4931465318	4058546234188
0029	1	BALL BEARING	4931465322	4058546234225
0032	1	BEARING COVER	4931465323	4058546234232
0034	5	SCREW	4931465324	4058546234249
0035	2	SCREW	4931465325	4058546234256
0036	4	SCREW	4931465326	4058546234263
0038	1	RATING PLATE	4931465347	4058546234478
0041	1	SWITCH LEVER	4931465328	4058546234287
0047	1	GEAR BOX HOUSING	4931465346	4058546234461
0048	1	BOLT	4931453279	4002395159307
0049	1	SPRING	4931436071	4002395878437
0050	1	LOCKING BOLT	4931436207	4002395883523
0052	1	HAMMER	4931465345	4058546234454
0053	1	PRESSURE SPRING	4931465344	4058546234447
0054	1	DRIVING SHAFT	4931465343	4058546234430
0055	3	PLANET GEAR	4931454518	4058546009465
0056	1	PROTECTION WASHER	4931436145	4002395880911
0057	1	WORM GEAR WHEEL	4931465342	4058546234423
0058	1	GEAR BOX HOUSING	4931465341	4058546234416
0062	1	SWITCH	4931465329	4058546234294
0063	1	GEARWHEEL SET	4931465340	4058546234409
0071	1	DRIVING SHAFT	4931465339	4058546234393
0072	1	ROTOR	4931465330	4058546234300
0073	1	ELECTRONIC SWITCH	4931465338	4058546234386
0090	1	HOUSING	4931465334	4058546234348
0091	1	CLAMP	4931436160	4002395880324
0701	1	CARRYING CASE	4931465335	4058546234355
0702	1	INSERT	4931465337	4058546234379